Tilting Jacks



Tilting Jacks

Rerailing with minimal effort.

Depending on the model, you can rerail some vehicles with a HP 25 / K 400 R jack, radius plate and wheel stop with minimal effort.

The diagonal stroke movement lifts and traverses the rail vehicle at the same time. The wheel stop stops the traverse movement as soon as the wheels are positioned over the rails.

Additionally, the tilting jack is used for uprighting rail vehicles with the lifting belt.

Required components (see picture above)

- (1) Tilting jack HP 25 / K 400R
- (2) Radius plate (3) Wheel stop Weight 18,6 kg